

VISIONQUEST™

THE ONLY COIN OPERATED
LASERDISC QUIZ GAME AVAILABLE

Kramer Manufacturing
451 Magnolia Avenue
Croydon, PA 19021
(800) 631-2126

Copyright Kramer Manufacturing
1992

V I S I O N Q U E S T

Set Up Instructions:

1. Plug AC cord into grounded outlet. Switch the power on by pushing the A.C. button switch which is located in the rear of the cabinet.
2. Unlock and open the laser disc player (LDP) compartment. (Door with two speakers on front of cabinet.)
3. Make sure LDP's power is on. A green light will appear above power switch. Open LDP door by pressing "open/close" switch on LDP. Take laser disc which is taped to top of LDP out of its jacket and place onto LDP with its white side facing upward. Never transport game with the disc in the laser disc player!!
4. Unlock and open the monitor door. Both the PCB shelf and monitor shelf slide partially out for ease of serviceability. Be careful not to pull either shelf so far out as to put an tension on any of the wires which are attached to the items on the shelves.
5. The service switch and volume control knob are located on the PCB shelf in front of the PCB. The volume control knob only controls the volume of the audio question in game play. As music is an integral part of the game, please ensure that the appropriate volume level is set for the location in which the game is placed. Never turn the volume all the way down. The volume of all other sounds is controlled by turning the potentiometer located on the main PCB in position RVI clockwise or counterclockwise with a small screwdriver or penknife.
6. Press the service switch one time to enter the service and option setting mode. Close the monitor door and use the "A," "B," and "C" buttons as instructed on the monitor. The monitor should read:
 - Press A for game options
 - Press B for service options
 - Press C to exit

If game options have been selected the monitor should read:

- Press A to select option
- Press B to change
- Press C to execute

6. Cont'd.

Option:

The first option (shown in pink at the bottom of the screen) will be "price of play." Push button "C" to execute and the "price of play" option. The current setting will appear on the 16 digit display.

Possible settings:

- (1) 25c/play
- (2) 50c/play and 3 play/\$1

Recommended setting:

~~50c/play and 3 play/\$1~~ 25¢ | PLAY

If you wish to change the current setting, push the "B" button until the desired setting appears on the display, then press the "C" button to execute that change.

To move on to the next option to be set, press the "A" button.

Option = Number of Lives

- Possible Settings = (1) 1 life
(2) 2 lives

Recommended Setting = 2 Lives

Press button "C" to enter this option setting, then press "B" until the desired setting is shown on the display and finally press "C" to execute that option setting.

Continue on to the "Bonus Life" option by pressing "A."

Option = Bonus Life

- Possible Settings = (1) 30,000 points
(2) 40,000 points
(3) 50,000 points

RECOMMENDED SETTING = 30,000 POINTS

Press button "C" to enter this option setting, then use "B" to change current setting, and finally use "C" to execute the change.

Once all options have been set you can return to the game program by pressing the service switch one time.

Service Testing:

- Press the service switch
- Press button A and B to select test and press button C to initiate that test

Possible Tests:

- Lamp Test
- Switch Test
- Monitor set-up size
- Color Bars
- Payout Solenoids (not applicable)
- Logic Sound
- Stereo Hi Fi Sound
- , Alpha Numeric Display
- Coin In Meter
- Coin Out Meter (not applicable)

Press the service switch one time to exit the service testing mode and return to the main game program.

OPERATION:

Visionquest is the only coin operated laser disc quiz game available. It utilizes movie quality pictures and stereo sound to pose questions to the player. There are five question types which may arise in a game: (1) Identify type, which will show an increasingly focused or increasingly larger portion of a picture and the player must identify the picture and choose the appropriate answer; (2) link type, the player must link the picture to the answer; (3) ~~avoid~~ Audio type, a segment of stereo music is played and the player must choose the appropriate answer as to the name of the song, name of the artist, etc.; (4) true/false type, a statement is made about the picture being shown and the player must answer true or false to that statement; and (5) study the picture type, a picture is put on the monitor and the player is told to study the picture. After approximately five seconds the picture is removed and the player is asked a question about the picture.

Each question has a maximum point value of 10,000 points and that point value decrements 1,000 points for each second the player takes to answer. When the score, which is shown on the alpha numeric display reaches 0, the player's time is up and subsequently he or she loses a life. A game starts with an operator settable number of lives, either 1 or 2, and each time the player answers a question incorrectly the player loses 1 life. The exception to the foregoing is on the first question of a game, the player gets a "try again" at no loss for answering incorrectly. A bonus life will be awarded to the player for reaching the operator settable bonus point level (30,000 points, 40,000 points, or 50,000 points). The game is over when the player has no lives remaining. If the player's score is one of the highest nine (9) scores to date, he or she will be given the opportunity to enter their initials in the Visionquest Hall of Fame.

WARRANTY AND LIMITATIONS

Kramer warrants that it has exercised the necessary care during the manufacture of its products to make them suitable for use as indicated. Kramer may, at its option repair or replace any nonconforming product without charge to the buyer. This warranty is in lieu of any other liability, nor are there any other warranties of merchantability and fitness for a particular purpose: Kramer disclaims any liability for any accidental or consequential loss, damage or expense directly or indirectly arising from the use of this product. Kramer will make any repairs to its equipment without charge to the buyer for a period of 120 days. This period shall begin on the date the equipment is received or purchased, whichever provides the longest coverage. Repairs and/or modifications made to this product without the expressed authorization of Kramer voids all warranties and liabilities. No representative of Kramer may change or alter any of the foregoing, and buyer hereby accepts the products subject to all the terms set forth herein.

OPERATOR WARRANTY 120 DAYS